



## Tissa Composites GmbH

Handelsware für Composites-Anwender

CH-5727 Oberkulm

Tel.: +41 62 768 86 66

Fax: +41 62 768 86 68

E-Mail: [composites@tissa.ch](mailto:composites@tissa.ch)

Internet: [www.tissa.ch](http://www.tissa.ch)

# MetroCat Dispenser for Catalysts

*Measures speedy and reliable!*

Dispensers allow to take the catalysts directly out of the original canister and at the same time it is exactly measured.

With MetroCat, most kind of aggressive liquids can be measured exactly, quick and clean.

An additional refilling is not necessary. The handling is easier and safer.

Most kind of viscosities can be used, but a test is requested before because most resins are charged. This dispenser is not for the use with PU-Hardeners because they tend to crystallise which harms the dispenser.

### How to use the MetroCat?

Just follow four easy steps:

1. Pull the handle down.
2. Insert hose into barrel with chemical.
3. Pull the handle up.
4. Dose the fluid with handle *(while pulling down)*.

Materials	
Axes	Steel
Bottom/ Top	PP
Cylinder	Glass
Piston	PTFE
Joints	Silicone
Housing	Aluminium, blue anodized
Hose	PE



Technical data		
Type	Quantity of Cylinder	Measures in mm
MetroCat MC-25	25 ccm	500 x 190 x 60
MetroCat MC-100	100 ccm	500 x 190 x 60
MetroCat MC-500	500 ccm	500 x 205 x 100